



Flexible compensation unit series FOUK-HT



HT-ZG32



- ① Through hole for mounting gripper
- ② Positioning for mounting gripper
- ③ Threaded hole for mounting truss
- ④ Positioning for mounting truss
- A Pushing test
- B Thrust spring

Note: The standard version of the product does not include the sensor, which is an optional item.



HT-ZG40



- ① Through hole for mounting gripper
- ② Positioning for mounting gripper
- ③ Threaded hole for mounting truss
- ④ Positioning for mounting truss
- A Pushing test
- B Thrust spring

Note: The standard version of the product does not include the sensor, which is an optional item.



HT-HE40



Mounting steps of gripper:
1.First remove ① through ⑤ .
2.Position on the gripper with the cylindrical locating pin through ③ .
3.Fix ④ on the corresponding gripper with the hexagon socket head cap screw through ② .
4.Finally, install and fix the two plates of ⑥ and ⑦ with ① through ⑤ .

- ① Hexagon socket head cap screw (standard)
- ② Through hole for mounting gripper
- ③ Positioning for mounting gripper
- ④ Threaded hole for mounting truss
- ⑤ Avoidance hole
- ⑥ Positioning guide strip
- A Pushing test
- B Pushing spring
- C Slider assembly
- D Rotary connecting plate

HT-HE50



Mounting steps of gripper:
1.First remove ① through ⑤ .
2.Position on the gripper with the cylindrical locating pin through ③ .
3.Fix ④ on the corresponding gripper with the hexagon socket head cap screw through ② .
4.Finally, install and fix the two plates of ⑥ and ⑦ with ① through ⑤ .

- ① Hexagon socket head cap screw (standard)
- ② Through hole for mounting gripper
- ③ Positioning for mounting gripper
- ④ Threaded hole for mounting truss
- ⑤ Avoidance hole
- ⑥ Positioning guide strip
- A Pushing test
- B Pushing spring
- C Slider assembly
- D Rotary connecting plate